

Market Arena Game Clock

MODEL # 008 3261

BEST PRACTICE:

Restart clock before every game (on/off button on the right side of the clock). Enter model #008 3261. Follow the prompts: Answer “NO” to shot clock, “YES” to penalty time out.

To Set Time:

Press **SET**

Press **TIME**

Enter **time 10:00 etc**

Press **YES**

Enter period 1, 2 or 3

To Enter a Score:

Press **SET**

Press **HOME SCORE** or **GUEST SCORE**

Enter the number **1, 2, and 3 etc.**

Press **YES**

Penalties:

Press **SET**

Press **HOME PENALTY** or **GUEST PENALTY**

Enter **Time 2:00, 4:00 etc...**

Enter 2 digit Player number (i.e. jersey #7 must be entered as 07)

Press **YES**

To Clear Penalties:

Press **HOME PENALTY** or **GUEST PENALTY**

Press **PENALTY CLEAR**

Press **YES**

Toggle Clock on and off as required using Toggle Switch located in top left corner of the display.